



TECH BULLETIN

TECH BULLETIN NUMBER	120713
PCR	ME-MR Remote staying in Battery Save Mode
DATE	7/13/2012
SUBJECT	Inverter staying in Battery Saver Mode with battery voltage below 12.6 VDC
MODELS AFFECTED	ME-MR Remote
REPAIR PROCEDURE	Identify revisions on inverter and remote. If the inverter is v5.4 and remote is v0.8 contact Magnum Energy.
WARRANTY	Regular warranties apply

To identify if action need to be taken:

1. Press the Menu button until the screen reads "TECH Press ON".
 2. Press the ON Button till you see "Inverter Rev *.*" and make note of the inverter revision.
 3. Press ON once more you will see "Remote Rev *.*" make a note of the Remote revision.
- If you note less than "Inverter Rev 5.0" no action needed.
 - If you note "Inverter Rev 5.4" and "Remote Rev 1.0" no action need.
 - If it reads "Inverter Rev 5.4" and "Remote Rev 0.8" remote needs to be upgraded to Rev 1.0.